

STANDARD

ASENNUSOHJE PÄÄLLEASENNUKSEEN

Huom! Käsittele allasta varoen, jottei allas vaurioituisi. Jos tuotteessa on huomauttamista, siitä on ilmoitettava myyjälle **ennen asennusta**. Asennuksen jälkeen tehtyjä valituksia ei voida hyväksyä.

Tarvittaessa kaapin rakennetta lovetta-
va esim. kiinnikkeitä ja ylivuotoa varten. Vaadit-
tavat loveukset tarkistettava aina asennus-
paikalla.

SÅGMALL FÖR OVAN MONTERING








Obs! Behandla hon varsamt, undvik att skada den. Har du anmärkningar på produkten, bör du meddela säljaren **före installationen**. Reklamationer som sker efter utförd installation godtas ej.

Vid behov måste en inskärning för t.ex. hofästena och bräddavloppet göras i skåpsstrukturen. Kontrollera alltid inskärningsbe-
hovet på plats.


INSTALLATION INSTRUCTION FOR INSET SINK

Note! When installing the product, handle it with care. Possible imperfections of the product have to be notified **before installation**. Claims for damage after the sink has been installed cannot be accepted.

If necessary, notch the cabinet structure, e.g. for fasteners and overflow. The required notches should always be checked at the installation site.



STANDARD



Clips 1153406 - YA-495, **14pcs/bag**

Stala Oy
Yrittäjänkatu 4, 15170 Lahti, Finland
Tel. +358 (0)3 882 1133
technical.support@stala.com

www.stala.fi
www.stala.se
www.stala.com
www.stala.no